

TRUCK MASTER Designs™

Air Dam Installation Instructions **'98-'03 Durango/'97-'04 Dakota**

DG816-S

YOU MUST PRE-FIT THE AIR DAM BEFORE PAINTING

Tools needed: flat screwdriver or V-blade pry tool, 18 mm socket, 10 mm socket, ½" drive ratchet, ¼" or 3/8" drive ratchet, 6-1/2" extension

1. To remove factory Air Dam, open hood and look to the left and right just behind the bumper. There are two 18 mm hex head bolts on each side on the top frame rails. Loosen the four bolts and remove one from each side, leaving one on each side temporarily.
2. From under the vehicle, using the flat screw driver or V-blade pry tool, remove the plastic push rivets that hold the rubber flap to the frame cross member and factory air dam..
3. Locate and remove the four 18 mm hex head bolts from the outside of each rail, two on each side just behind the driving lights. Disconnect the driving light wiring harness from the driving lights.
4. Pull the plastic inner fender lips out from behind the bumper and air dam.
5. Remove the top two loosened bolts and carefully remove the bumper and air dam from vehicle.
6. Turn the bumper upside down, then using the 10 mm socket remove the factory air dam from the bumper.
7. Install the painted Truck Master Designs' Air Dam onto the bumper using the supplied hardware, then reinstall the bumper back onto the vehicle.

Warranty is void if Air Dam is not prefitted to factory bumper before painting and permanently installing.

www.TruckMasterDesigns.com