

TRUCK MASTER Designs™

JP765

2003-2004 Jeep Wrangler TJ Steel Steering Box Skid Plate

Tools needed: Power Drill
11/32 Drill Bit
½" Drive Ratchet
16mm Socket
9/16 Shallow Socket
Torque Wrench

1. Using ratchet and 16mm socket, remove front and rear bolts from driver side of factory steering box. NOTE: DO NOT LOOSEN CENTER BOLT
2. Position Truck Master Designs' Steering Box Skid Plate and re-install the bolts that were removed; torque to 50 ft. lb.
3. Using the mounting hole in the Skid Plate Support Bracket as a guide, drill a 11/32 hole into the round frame cross tube.
4. Using the ratchet and 9/16 socket, firmly push and turn the self tapping hex bolt until the bolt starts threading into the tube. Firmly snug this bolt but do not over tighten.

Happy Four Wheeling
www.TruckMasterDesigns.com